



CONFIGURING WIRELESS NETWORK SELECTION


1. Log in as the administrator.
2. Press the ▼ to select **Network Menu**, and then press the ►.




3. Press the ▼ to select **Network Setup**, and then press the ►.




4. Press the ▼ to select **Wireless Setting**, and then press the ►.




5. Press the ▼ to select **Wireless Network Selection**, and then press the ►.



6. The product starts to search the wireless access point.



7. A list of access points found by the search will be displayed. Select the access point you wish to connect to using the ▲ ▼ keys, then press **OK**.



8. Enter the security password of the selected access point.

(1) With WEP

Enter the WEP key will be displayed. Enter the encryption key using the ▲ ▼ ► ◀ keys, and press **OK**.

The first screenshot shows the 'Wireless Setting' menu with the option 'Enter the WEP key.' selected. Below the menu is a black bar with a right-pointing arrow. At the bottom are 'Previous' and 'Next' buttons.

The second screenshot shows the 'Enter the WEP key.' screen with a character input grid. The grid includes symbols, letters, and numbers. To the right of the grid are 'Cancel' and 'Done' buttons. A progress indicator '0/26' is in the top right corner.

Go to Section 9

(2) With WPA-PSK or WPA2-PSK

Enter the Pre-shared key will be displayed. Enter the encryption key using the ▲ ▼ ► ◀ keys, and press **OK**.


The first screenshot shows the 'Wireless Setting' menu with the option 'Enter the Pre-shared Key.' selected. Below the menu is a black bar with a right-pointing arrow. At the bottom are 'Previous' and 'Enter' buttons.

The second screenshot shows the 'Enter the Pre-shared Key.' screen with a character input grid. The grid includes symbols, letters, and numbers. To the right of the grid are 'Cancel' and 'Done' buttons. A progress indicator '0/64' is in the top right corner.

Go to Section 9

(3) With WPA-EAP or WPA2-EAP


Configure settings from Web Page.




(4) With Disable

The password input screen will not be displayed. Go to Section 9.

9. In the confirmation screen, please check the contents on the confirmation screen, select **Yes**, and press **OK**.



10. Connection successful will be displayed once you have successfully connected to the wireless LAN.



MEMO

> If unable to connect to a wireless LAN, **Connection failed** will be displayed and you will be returned to the Wireless Settings screen in Section 5.
