

MICROLINE 320 TURBO ESC/P Print Driver Instructions

These instructions are separated into two sections depending on how your printer is connected.

USB Setup = Printer connected directly to the computer with a USB cable.

Network Setup = Printer connected to the network/router with an Ethernet cable.

Download the ESC/P Printer Driver

Copy and paste the link below into your web browser:

<https://www.oki.com/us/printing/support/drivers-and-utilities/dot-matrix-printers/62411601/>

1. Click on ESC/P Printer Driver.
2. Read the software agreement.
3. Click DOWNLOAD UPON AGREEING WITH THE SOFTWARE AGREEMENT.
4. Double click on the downloaded EXE file.
5. Follow the on-screen prompts to extract the driver files.
6. Click Open File at the bottom left of the PC screen if prompted.
7. Click Yes.
8. Click Next.
9. Click Accept.
10. Click Next.
11. Click Install.
12. Wait for the installation to complete.
13. Click Finish.

USB Setup - Printer Connected with USB Cable

14. Connect the USB cable from the printer directly to the computer.
15. Open Settings.
16. Click Bluetooth & devices.
17. Click Printers & scanners.
18. Click Add device.
19. Click Add a new device manually.
20. Select Add a local printer or network printer with manual settings.
21. Click Next.
22. Select Use an existing port.
23. Select LPT1.
24. Click Next.
25. Click Have Disk.
26. Browse to C:\OKIDATA\ML3201
27. Click OK.

28. Select the ML320T printer.
29. Click Next and Finish.
30. After the printer installs, go back into Printer Properties.
31. Click the Ports tab.
32. Change the printer port back to USB001 or USB002.
33. Click Apply and OK.
34. Click Print Test Page.

Important: During USB installation the printer must temporarily be installed on LPT1 or the installation may fail. After the installation is complete, change the port back to the original USB001 or USB002 port and click Apply and OK to save the changes.

Network Setup - Printer Connected with Ethernet Cable

Before starting, make sure the printer is connected to the router or network switch with an Ethernet cable and that you know the printer IP address.

35. Open Settings.
36. Click Bluetooth & devices.
37. Click Printers & scanners.
38. Click Add device.
39. Click Add a new device manually.
40. Select Add a local printer or network printer with manual settings.
41. Click Next.
42. Select Create a new port.
43. Select Standard TCP/IP Port.
44. Click Next.
45. Enter the printer IP address.
46. Click Next.
47. Click Have Disk.
48. Browse to C:\OKIDATA\ML3201
49. Click OK.
50. Select the ML320T printer.
51. Click Next and Finish.
52. Click Print Test Page.