

Chapter 2: Loading Paper

Your printer has provision for single-sheet paper feed from the top and for continuous-form paper feed from the rear. You can also install options: the Cut Sheet Feeder, which holds a stack of 100 sheets for feeding from the top and the Push and/or Pull Tractors for feeding continuous-form labels, heavy card stock or multi-part forms from the bottom. See Chapter 5 for more information on these options.

Top Feed

- Single sheets (basis weight 14 to 24 lbs)
- Single envelopes
 - 24-lb maximum
 - 6.5" to 9.5" wide
- Transparencies (8.5 x 11")

Rear feed (continuous forms only, thickness to 0.014" [0.36 mm])

- Single-part continuous forms
 - 12 to 24 lb.
 - Minimum 3" wide
 - Carbonless, multi-part forms
 - Original, plus 3 copies
 - 9 to 11 lb
 - Minimum 3" wide
 - Interleaf, multi-part forms (with carbon paper)
 - Original, plus 3 copies
 - 10 to 12 lb paper, with 9 lb carbon
 - Minimum 3" wide
-

Bottom feed (continuous forms only, thickness to 0.017" [0.44mm])

- Single-part continuous forms
 - 12 to 24 lb
 - Minimum 3" wide
- Carbonless, multi-part forms
 - Original, plus 4 copies
 - 9 to 11 lb
 - Minimum 3" wide
- Interleaf, multi-part forms (with carbon paper)
 - Original, plus 4 copies
 - 10 to 12 lb paper, with 9 lb carbon
 - Minimum 3" wide
- Continuous-feed envelopes
 - 24 lb maximum
 - 6.5" to 9.5" wide (envelope itself)
- Labels
 - minimum 3" wide
 - maximum 10" (ML320 Turbo Plus) or 16" (ML321 Turbo Plus) wide
- Card stock: papers up to 120 lb maximum