

OKI SIDM Quick Reference Table

SIDM Local Tests and Menu Modes

Description of Local Test or Menu	ML186	ML300T Series	ML400 Series	ML500 Series	ML395	PM3410	ML8810	PM4410
Font/Self Test Mode (while turning on power)	LF	LF	LF	LF	LF	LF	Mode & LF	LF
Rolling ASCII Test (while turning on power)	SEL & LF	Quiet	Quiet	Quiet	Park	FF	LF & FF	Path/TOF
Hex Dump Mode (while turning on power)	SEL & FF	SEL & FF	SEL & FF	SEL & FF	SEL & FF	SEL & FF	Mode + LF + Shift	FF/Load
Factory Default Reset (while turning on power)	SEL & TOF	FF & Tear	SEL & LF	SEL & LF	SEL & Park	SEL & LF	SEL, FF, Load, & Mode	Option & Store
Print Menu Settings	Select	Shift & Select Shift & Print	Shift & Select Shift & Print	Shift & Select Shift & Print	Deselect-Quiet Print	Qual & Pitch Print	Select & Mode (on power up)	Menu Shift & Menu
Enter Printer's Menu Mode	Select (on power up)	Shift & Select	Shift & Select	Shift & Select	Quiet (on power up)	Qual & Pitch	Shift & Mode (after de-selecting)	Menu
a) Move to next group	LF	Group	Group	Group	Group	Group	Shift & FF up or LF down	Group
b) Move to next item	FF	Item	Item	Item	Item	Item	FF up or LF down	Item
c) Change & save a setting (while in Menu Mode & online)	TOF	Set	Set	Set	Set	Set	Mode or SEL	Store
Save settings and exit Printer's Menu Mode	Pitch & Mode	Shift & Select	Shift & Select	Shift & Select	Exit	Exit	Load	Menu

Key: LF = Line Feed SEL = Select FF = Form Feed TOF = Top Of Form